Audit probe:

Bracket assembly, general notes follow.

1. Remove burrs and break sharp edges.
2. Finish: anodise clear, 10 um minimum.

あう

DRAWING 4471-220
SHEET 1 OF 1
SCALE 1:1