Layer probe

Bracket assembly, general notes follow.

1. Remove burrs and break sharp edges.

150

Field note: verify anchor bolts