Procedure

Follow these steps in order:

1. Isolate the electrical supply at the main board.
2. Notify the site supervisor of the isolation.
3. Apply a lock and personal danger tag.
4. Test for dead with an approved voltage tester.
5. Commence work on the circuit.
6. Remove locks only when work is complete.

Record each isolation in the permit register.