Audit probe:

Bracket assembly, general notes follow.

1. Remove burrs and break sharp edges.
2. Finish: anodise clear, 10 um minimum.

R1	R2	C1	C2
5.1k	10k	100n	22p

DRAWING 4471-220
SHEET 1 OF 1
SCALE 1:1